


TE-301 사용설명서

각 부분 명칭



제품특징

- 보기 편한 대형 LCD 표시부
- 0.1℃ 단위로 정밀한 온도 표시
- 탁상용 또는 벽걸이용으로 사용가능
- 쾌적/불쾌 지수 아이콘

제품특징

- 실내 온습도 측정
 - 1) LCD창 위의 보호 필름을 제거하십시오.
 - 2) 제품 뒷면에 건전지 커버를 열고 절연 시트를 제거한 후 전원이 켜지는지 확인하십시오.
 - 3) 제품을 안정된 장소에 설치하십시오.
 - 4) 쾌적/불쾌 지수 아이콘 표시 기능

쾌적/불쾌	DISPLAY	아이콘	↑ 쾌적 ↓ 불쾌
50~60 %	55 RH %	^^	
21~49 %	34 RH %	>>	
~20 %	LO	>>	
61~90 %	65 RH %	>>	
91%~	HI	>>	

제품 사양

품 명	디지털 온습도계
모 델 명	TE-301
사용 온도	-5℃ ~ +40℃
습 도	20% ~ 95% (RH)
규 격(mm)	95(W) x 98(D) x 20(H)
제 품 전 원	DC 1.5V AAA 전지 2개

건전지 교체 방법

1. 온/습도 표시부의 숫자 표시가 흐려졌을 경우 전지를 교체해 주세요.
2. 1.5V AAA 전지 2개를 준비하세요.
3. 제품 뒷면에 전지 커버를 열고 방전 된 전지를 빼내세요.
4. +/- 표시에 맞춰 전지를 삽입하신 후 전지 커버를 닫아주세요.
5. 전지 교체 후 온도와 습도를 재 측정하는 데는 약간의 시간이 소요됩니다.
6. 사용이 끝난 전지는 어린이의 손에 닿지 않는 곳에 보관하시고, 장시간 사용하지 않을 때는 반드시 전지를 제품에서 분리하여 보관해주세요.

* 제품에 삽입되어 있는 전지는 작동 확인용 이므로, 전지 수명이 짧을 수 있습니다.

Thermometer & Hygrometer Operation Instructions

Feature

It is called "indoor thermometer", be applicable to measure the indoor temperature and humidity.

Functions of the button

Button : the button could displaying face.

Function reference parameter

1. Power supply voltage : 1.5V (2 * AAA)
2. Unit : °C
3. Temperature measurement scope : -5 °C ~ +40 °C
4. Humidity measurement scope : 20%RH ~ 95%RH
5. When the humidity value is 91% or more humidity value scope, the LCD will displaying



6. When the humidity value is 61% - 90% humidity value scope, the LCD will displaying



7. When the humidity value is 50% - 60% humidity value scope, the LCD will displaying



8. When the humidity value is 21% - 49% humidity value scope, the LCD will displaying




9. When the humidity value is 20% or less humidity value scope, the LCD will displaying




Operating instructions

Power on, starting showing all <picture 1>, then measuring temperature and humidity displaying screen as <picture 2>



<picture 1>



<picture 2>